

1. Install Wallboard according to manufacturer specifications.



2. Apply adhesive or thinset.



4. Place Corner Shower Shelf in desired location.



5. Apply thin-set and your choice of finished product.



floatingshowerbench.com 888-584-1112

Bench can be cut down to Customized Specifications.