

Preparation for installation – Magnetic gap seal (DIY kit)

Preparation

Choose a surface that is as flat and clean as possible on which to lay out and work on the DIY kit.

Cutting

Cut the DIY kit to the desired dimensions. Ideally, use a suitable cutting mat to protect the surface and enable precise cuts.

Installation

1. Peel off the protective film from the double-sided adhesive tape **step by step**.
2. Carefully position the film so that the crease edge is aligned exactly with the bottom edge.
3. Coat the entire surface evenly to ensure clean and secure adhesion.



Assembly

The prepared gap seal can now be mounted on the loading bridge. For complete and safe assembly, please also refer to the separate assembly instructions.

Safety instructions

Personal protective equipment

Wear suitable **safety gloves** to avoid injury.

Warnings

Caution: Risk of cuts! Take care when cutting and handle tools safely.