



**Note!**

Please note that this image is a general representation of the product and may differ slightly from your product.

**Note!**

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

**Kit Contents**

Description	Part No	Pcs
Shock absorber left/right rear	POR6L00	1
Sticker Öhlins	00192-01	2
Owner's manual	07440-01	1

**Warning!**

Before installing this product, read the Öhlins Owner's Manual. The shock absorber/front fork/steering damper is an important part of your vehicle and will affect the stability.

## Shock absorber for Porsche 911 Historic - rear

# **POR 6L00**

## Mounting Instructions

# MOUNTING INSTRUCTIONS


## **Warning!**

*It is advisable to have an Öhlins dealer install the shock absorber.*

---

 *When installing, read the Vehicle Service Manual.*

---

 *When working on a raised vehicle, ensure the vehicle is securely supported so that it will not tip.*

---

**1**

Raise the vehicle so that both rear wheels not touch the ground.

**2**

Remove the nut of the upper mount from inside the vehicle.

**3**

Remove the nut and bolt from the lower attachment and remove the original shock absorber.

**4**

Install the Öhlins shock absorber. Insert the lower attachment bolt and nut.

**5**

Mount the upper attachment nut from inside the vehicle.

## **Caution!**

*Ensure that all screws are tightened to the correct torque and that there are no binds and that nothing restricts movement of the shock absorber when the suspension is being fully compressed or extended.*

---

# MOUNTING INSTRUCTIONS

