

Under Cut Barber Station

K7600

This unit ships in 3 boxes

1. Large box is the base unit
2. Large thin box is the mirror and back panel
3. Small rectangle box is shelf

1st open the large base box, open the mirror box next this box has the mirror, mirror brackets and hardware. Next position the mirror brackets by lining the holes up with the holes on the back side of the base. Using the bolts and washers provided screw the bolts into the holes.

note do not tighten bolts yet

The mirror brackets need to be able to move a little to align mirror into position. Carefully place the mirror back panel onto the base. *note this may need two people* align the mirror brackets to the back panel. Once in place use the remaining bolts and washers to secure to unit. Go through now and tighten all bolts. **DO NOT OVER TIGHTEN.** Now place the mirror on the back panel. Use the chrome

*head bolt to secure mirror to back panel * again do not over tighten.**

Last slide shelf over mirror and back panel the metal brackets will hold the shelf in place. Note shelf can be placed on either side of the unit. Now you're ready for your plumber to install faucet and piping.