



KELLER INTERNATIONAL, LLC

1431 LAKE RD, HAMLIN NY 14464

Info@kellerinternational.com

T: 1-800-578-8772 • F: 1-585-964-8093

KELLER4SALON.COM

KM-S813 Pedicure Spa – Cut Sheet

Installation

The installation must comply with your Local building, plumbing and electrical codes (where applicable). A licensed plumber should complete the plumbing of the foot spa.

Location:

Select a level location where the floor structure beneath the Foot spa is capable of supporting the Foot spa. For the seat back to fully recline the Foot spa base must be mounted a minimum of 20 to 24 inches from the wall. This allows the chair to recline all the way back.

