

Instructions to install 9600 track:

Remove end caps and cut track/s to desired length with a hack saw. If your tracks are spliced, it is best to cut the ends with the end caps. The spliced area has been machine cut for a smooth joint. Mark the ceiling 3 ½" away from the wall or at the desired projection. Drill a hole within 6" of the end of each track section and one near the middle. Use a small drill bit (a wood drill bit is fine. Aluminum is a soft metal and easy to drill). If you know that you are screwing into wood or metal, proceed to screw up through the center of the channel into the ceiling using the self-drilling screws and bit provided. Be careful not to damage the sides of the track channel. Put one screw within 6" of the end of each track section and one in the middle. If installing multiple track sections, carefully align the joint and test with a wheeled carrier.

If installing in hollow ceiling, mark the holes on the ceiling and drill the appropriate sized hole for your anchor. Insert hollow wall anchors (not provided) any place needed. For very heavy draperies, toggle bolts are recommended. If using screws other than what's provided (like toggle bolts), be sure the head of the screw will fit in the 5/16" channel of the track (1/8" x 2 in. toggle bolts will typically work). Lift the track back up to the ceiling, realigning with the holes and screw into place.

Extra parts can be purchased at curtainrodconnection.com/collections/9600-cubicle-track-parts

Instructions to install 9600 track:

Remove end caps and cut track/s to desired length with a hack saw. If your tracks are spliced, it is best to cut the ends with the end caps. The spliced area has been machine cut for a smooth joint. Mark the ceiling 3 ½" away from the wall or at the desired projection. Drill a hole within 6" of the end of each track section and one near the middle. Use a small drill bit (a wood drill bit is fine. Aluminum is a soft metal and easy to drill). If you know that you are screwing into wood or metal, proceed to screw up through the center of the channel into the ceiling using the self-drilling screws and bit provided. Be careful not to damage the sides of the track channel. Put one screw within 6" of the end of each track section and one in the middle. If installing multiple track sections, carefully align the joint and test with a wheeled carrier.

If installing in hollow ceiling, mark the holes on the ceiling and drill the appropriate sized hole for your anchor. Insert hollow wall anchors (not provided) any place needed. For very heavy draperies, toggle bolts are recommended. If using screws other than what's provided (like toggle bolts), be sure the head of the screw will fit in the 5/16" channel of the track (1/8" x 2 in. toggle bolts will typically work). Lift the track back up to the ceiling, realigning with the holes and screw into place.

Extra parts can be purchased at curtainrodconnection.com/collections/9600-cubicle-track-parts

Instructions to install 9600 track:

Remove end caps and cut track/s to desired length with a hack saw. If your tracks are spliced, it is best to cut the ends with the end caps. The spliced area has been machine cut for a smooth joint. Mark the ceiling 3 ½" away from the wall or at the desired projection. Drill a hole within 6" of the end of each track section and one near the middle. Use a small drill bit (a wood drill bit is fine. Aluminum is a soft metal and easy to drill). If you know that you are screwing into wood or metal, proceed to screw up through the center of the channel into the ceiling using the self-drilling screws and bit provided. Be careful not to damage the sides of the track channel. Put one screw within 6" of the end of each track section and one in the middle. If installing multiple track sections, carefully align the joint and test with a wheeled carrier.

If installing in hollow ceiling, mark the holes on the ceiling and drill the appropriate sized hole for your anchor. Insert hollow wall anchors (not provided) any place needed. For very heavy draperies, toggle bolts are recommended. If using screws other than what's provided (like toggle bolts), be sure the head of the screw will fit in the 5/16" channel of the track (1/8" x 2 in. toggle bolts will typically work). Lift the track back up to the ceiling, realigning with the holes and screw into place.

Extra parts can be purchased at curtainrodconnection.com/collections/9600-cubicle-track-parts