

Instructions to install 94001 track:

If your track is spliced, lay the track on the floor upside down. Loosen splice in center and slide over so it hangs halfway off the track (if not already done). Slide the other half of the track into the splice. The splice should be centered on the 2 pieces of track. Tighten screws on splice making sure the track channel is aligned.

Mount 2 supports within 6" of the end of the track. Mount the other supports level with the first ones, spacing them no further than 48" apart. Be sure not to put a support right where the splice is.

With help, lift the track to the underside of the supports, hooking the front lip on the top of the track to the front of the supports. Turn the zinc-colored retaining clip so that it covers the back lip of the track and then tighten the screw so that it clamps onto the back lip.

Install the cord pulley down at the baseboard, directly below the cord. Lift the top part of the pulley (it is spring-loaded) and insert a nail or paper clip in the hole, holding it in the up position. Insert the cord in the pulley.

Reach behind the master carrier that has the two knots from the cord. Grab the knot that is closest to the cord side and pull the cord until all the slack of the cord is out. Cut the cord, leaving it about 6" long. Re-tie the knot as close to the back of the master carrier as possible while keeping the cord tight. Cut off the rest of the excess cord. Go back down to the cord pulley at the baseboard and remove the nail.

See the following instruction video on our website:

<https://curtainrodconnection.com/pages/installation-instructions>

Instructions to install 94001 track:

If your track is spliced, lay the track on the floor upside down. Loosen splice in center and slide over so it hangs halfway off the track (if not already done). Slide the other half of the track into the splice. The splice should be centered on the 2 pieces of track. Tighten screws on splice making sure the track channel is aligned.

Mount 2 supports within 6" of the end of the track. Mount the other supports level with the first ones, spacing them no further than 48" apart. Be sure not to put a support right where the splice is.

With help, lift the track to the underside of the supports, hooking the front lip on the top of the track to the front of the supports. Turn the zinc-colored retaining clip so that it covers the back lip of the track and then tighten the screw so that it clamps onto the back lip.

Install the cord pulley down at the baseboard, directly below the cord. Lift the top part of the pulley (it is spring-loaded) and insert a nail or paper clip in the hole, holding it in the up position. Insert the cord in the pulley.

Reach behind the master carrier that has the two knots from the cord. Grab the knot that is closest to the cord side and pull the cord until all the slack of the cord is out. Cut the cord, leaving it about 6" long. Re-tie the knot as close to the back of the master carrier as possible while keeping the cord tight. Cut off the rest of the excess cord. Go back down to the cord pulley at the baseboard and remove the nail.

See the following instruction video on our website:

<https://curtainrodconnection.com/pages/installation-instructions>