

Instructions to install 94003 track:

Remove end caps and cut track/s to desired length. If your tracks are spliced, it is best to cut the ends with the end caps. The spliced area has been machine cut and filed for a smooth joint.

If your track is spliced, lay the track on the floor upside down. Loosen splice in center and slide over so it hangs halfway off of the track. Slide the other half of the track into the splice. The splice should be centered on the 2 pieces of track. Tighten screws on splice making sure the track channel is aligned.

Mount 2 supports within 6" of the end of the track. Mount the other supports level with the first ones, spacing them no further than 48" apart. Be sure not to put a support right where the splice is.

With help, lift the track to the underside of the supports, hooking the front lip on the top of the track to the front of the support. With a flat head screw driver inserted into the slot on the metal cam underneath the support, turn the cam counterclockwise, locking in the track.