

Invisible Ceiling Mount Installation

Place a ceiling clip on top of the rod within 6" of each end and spaced no more than 48" apart. Put one on any spliced joint that you have. You may have to pry them open slightly or slide them on from the end.

Put screws in the ceiling, using anchors if not installing in wood. Leave them loose enough to insert the keyhole opening on the back of the brackets into the screw. Tighten the screws.

Alternatively, you can put the ceiling clips on, lift the rod up to the ceiling and drive the screws through the hole in the back of the brackets.

There is no need to put a screw in the small hole of the ceiling clip that is on top of the track.

