

## **Motiva-** bracket instructions

Mount the bracket bases level across the wall, putting one near each end of the track and the rest evenly spaced. When spliced, put a bracket near the splice, but it can't go directly on the splice. Space the brackets no more than 48" apart.

Loosen the small screw on the underside of the base and remove the adjustable front stem part of the bracket that attaches to the track. Loosen the screw and square nut on the front stem enough to slide it into the top channel of the track from the end. Leave slightly loose but slide them along the top of the track to equal the approximate location of the base brackets on the wall.

Lift the track up to the brackets, adjust the front stem pieces so they align with base brackets on the wall. Insert them back into the base brackets. Tighten both screws again to secure in place.

