

Tekno 25 double bracket installation:

Mount the L shaped base brackets to the wall. Put the first bracket within 6" of each end of the track. If track is spliced (see other instruction page), put a bracket over the joint, covering the seam. This will strengthen the joint. If the sections of track are more than 6 feet and/or the draperies are heavy, add another bracket between the end and each splice.

Take the C clips and slide them onto the track as shown in the pictures below. Leave the set screw slightly loose so you can adjust the C clips to line up with the L shaped base brackets mounted to the wall.

Remove the top screw on the C clips, lift the track up to the underside of the L bracket and put the top screw in, connecting the L bracket to the C clips.

Tighten the set screws on the C clips. You may need to have the C clip set screw on the back rod facing front, unless you have a very small or angled screw driver.

