

Wave fold drapery installation instructions

Curtain Rod Connection

1. Lay your panels down on a bed, table or flat surface.
2. Slide the 3" chains onto the hooks, connecting only the hooks spaced 6" apart.



3. Lift panels up to the rod. Insert the hooks into the slides on the track.
4. Dress down wave folds, add paper straps and leave for a day or two to create fold memory.

