

HOW TO TAKE PHOTOGRAPHS AND MEASUREMENTS OF YOUR PEDALS

IF YOU ARE ORDERING AN 'ARDCASE FOR A SERIES LAND ROVER (1, 2, 2A, 3)
OR A CUSTOM BUILT 'ARDCASE.

1. Place a rule or tape measure across all 3 pedals and secure it in position so it cannot move. ("Blu-Tack" works well). Take a photograph as shown in photograph 1 (right).



2. Take another clear photograph with the camera positioned **directly** in front of the clutch pedal, as shown in photograph 2 (right).



3. Take another clear photograph with the camera positioned **directly** in front of the brake pedal, as shown in photograph 3 (right).



4. Take another clear photograph with the camera positioned **directly** in front of the accelerator pedal, as shown in photograph 4 (right).



email the four photographs to info@trekoverland.com when you place your order.

The photographs below show a custom built 'ardcase supplied recently to a customer with a fabulous Series vehicle. The customer supplied excellent clear photographs which resulted in a perfect fit on the pedals.

