

NEUSPEED®

BOOST TAP

2014-UP AUDI A3 (8V) 1.8 TSI/2.0 TSI
2013.5-UP VW GLI & BEETLE 2.0 TSI 210HP
2015-UP VW GOLF 1.8 TSI & GTI MK7

PART #49.10.96

INSTALLATION INSTRUCTIONS

- PARTS LIST:** 1 - BILLET BOOST TAP 1 - M6X14MM SS BUTTON HEAD SCREW
TOOLS LIST: 1 - T20 TORX 1 - 4MM HEX KEY WERNCH



1. Lift up engine cover to remove.



2. Remove sensor mounting screw using T20 torx, then push outward on retaining tabs and pull out sensor from intake manifold.



3. Push side retaining clips outward, and then pull out boost sensor from intake manifold.



4. **NOTE:** Before installing Boost Tap, if a different boost gauge sensing line fitting is to be used install now.

Lightly oil "O" ring, then install *NEUSPEED* Boost Tap into intake manifold using original T20 Torx screw. **WARNING!** Do not over tighten screw into plastic manifold.



5. Lightly oil "O" ring on original boost sensor and install into *NEUSPEED* Boost Tap, tighten using supplied M6x14mm SS button head screw.

6. Install your boost gauge and sensing line to Boost Tap then reinstall engine cover.

Copyright 2014, *NEUSPEED*®.
All rights reserved. Reproduction in whole or in part prohibited.
DOC. 49.10.96 Rev. 05.22.14