



Radiator Bracket

Installation Instructions for Part #s:

555-01932, 555-01934, 555-01936, 555-01938
555-0602, 555-0604, 555-0606, 555-0608

- 1) Remove the bolts holding the original radiator brackets. Lift the brackets off of the radiator.
- 2) Lay the new radiator bracket on the radiator and core support to check the fit.

There are a large variety of radiators being used, so the bracket will not fit the same on all cars. On some cars you will have to move the wiring harness (in front of the radiator) down out of the way so that you can pull the radiator forward enough for the bracket to reach.

Two spacers are included to raise the radiator bracket to clear the airbag sensor bolts on 1990-1993 Mustangs. These spacers may be needed for best fit on mustangs with certain radiators. Try fitting the bracket on with and without the spacers to find the best fit on your car.

- 3) Bolt down the new radiator bracket.