

Steeda

S197 GT Strut Tower Brace

Installation Instructions

555-5716 & 555-5718

Note: 555-5718 for V6 skips Steps 1-6

Instructions

1. Remove 2 nuts holding plenum cover to throttle body (8mm wrench)
2. Pull up on wiring loom hanger attached to stud between runners on driver's side.
3. Carefully pull up on back of plenum cover until the grommets clear the studs; then pull forward until front grommets clear throttle body studs.

Note: If so desired, the plenum cover can be left off. Proceed to Step 6 if plenum cover is to be omitted.

4. Remove grommets from rear legs.
5. Re-install plenum cover by aligning the studs on the throttle body with the grommets on the cover, slide rearward until the rear legs are in position, and then lower the rear onto the rear studs. Secure with the factory nuts.
6. Return the wiring loom hanger to the rear stud on the driver's side.
7. Remove the inner strut mount nuts on both strut towers.
8. Place the strut tower bar onto the exposed strut mount studs with the taller bar toward the rear.
9. Re-install the factory nuts to the strut mount studs and tighten.

