



**GEN 1 TSI CRANK PULLEY
INSTALL INSTRUCTIONS**



STEP 1: REMOVE UNDERBELLY PAN AND PASSENGER INNER FENDER LINER

STEP 2: POP BOTH CLIPS AND REMOVE BOTH BOLTS HOLDING DISCHARGE PIPE. PULL DISCHARGE PIPE FREE

STEP 3: USING 17MM WRENCH, PULL IDLER PULLEY UPWARDS AND REMOVE BELT

STEP 4: USING 24MM SOCKET, TURN CRANK PULLEY TO TOP DEAD CENTER. ALIGN MARKS ON PULLEY AND COVER. LOOSEN PULLEY USING LONG HANDLE BREAKER BAR AND 24MM SOCKET.

STEP 5: INSTALL NEW PULLEY USING NOTCHED KEYWAYS ON BACK OF PULLEY. HAND TIGHTEN REPLACEMENT BOLT.

STEP 6: TORQUE BOLT TO 150Nm (111 FT,LBS) + 90° USING COUNTER HOLDING TOOL T10355 AND TORQUE WRENCH.

STEP 7: INSTALL REPLACEMENT BELT. REINSTALL DISCHARGE PIPE, FENDER LINER AND UNDERBELLY PAN COVER.