INSTALLATION GUIDE



MK7 VW GTI AIR INTAKE

TOOLS REQUIRED:

T25 Torx Bit 10mm Socket 8mm Socket **Pliers**



WHAT'S IN THE BOX:

- 1 Air Intake Pipe 1 (Optional) Heat Shield
- 1 Green Filter
- 1 Velocity Stack
- 1 SAI Filter
- 1 Mounting Screw 2 Couplers
- 4 Small Clamps
- 1 Large Clamp



1. DISCONNECT THE BATTERY



2. POP OFF ENGINE COVER



3. DISCONNECT SECONDARY AIR PUMP HOSE AND VACUUM LINE - PINCH AND PULL



4. REMOVE FRONT VENT FOR AIRBOX

5. DISCONNECT TURBO INLET PIPE CLAMP







6. REMOVE STOCK AIRBOX

7. OPTIONAL HEAD SHIELD INSTALL

8. CLICK INTO PLACE









9. INSTALL COUPLER



10. ATTACH MAP INTAKE AND TIGHTEN AT REAR



11. ATTACH SUPPLIED BOLT TO THE HIGH PRESSURE FUEL PUMP HOUSING



12. ATTACH AND ZIP TIE VACUUM HOSE To Brass Barb on Intake



13. INSTALL COUPLER TO VELOCITY STACK THEN COUPLER TO FILTER



14. CONNECT VELOCITY STACK TO CHARGE PIPE AND TIGHTEN



15. REMOVE BELLY PAN - T25 TORX



16. DISCONNECT AND REMOVE SECONDARY AIR PUMP HOSE



17. CLICK FILTER ON AND REINSTALL BELLY PAN



18. SECONDARY AIR PUMP HOSE



19. RECONNECT BATTERY, ENGINE COVER AND AIR VENT - DONE!







THANK YOU FOR CHOOSING MAPERFORMANCE!

If you have any problems or concerns during installation of this product, feel free to call or email us:

1-888-MAPERFORMANCE
ajohnson@maperformance.com
Show us some photos! @maperformance / #maperformance