

Instruction Manual P/N:SP1350

NOTE: This intake kit may not work on vehicles with the following aftermarket modifications.

- Aftermarket Intercooler piping
- Aftermarket intercooler
- Turbo upgrade
- Modified body panels
- Suspension & Chassis modifications

Injen intake systems are street legal in most states unless the state is adopting to California Emissions standards. States that have adopted California emission standards include: Arizona, California, Connecticut, District of Columbia, Maine, Maryland, Massachusetts, New Jersey, New Mexico, New York, Oregon, Pennsylvania, Rhode Island, Vermont, and Washington. These states will require an California Air Resource Board Executive Order Number (CARB E.O.) for the legal use of an Injen intake system in your vehicle for use on public roads or highways. These vehicle will be considered "Legal in California only for racing vehicles competition use only, which may never be used upon a public street or highway. **Please keep your factory air box assembly for any future use.**



The SuperNano-Web filter media is a dry synthetic media that outperforms the competition. The media itself is a proprietary base blend of synthetics and cellulose. Cellulose fibers are larger than synthetic fibers, and have larger spaces between the fibers, causing contaminants to load in the depth of the media and plug the airflow path. This creates higher restriction levels and less capacity. The synthetic fibers in the SuperNano-Web media are submicron in diameter and have small interior fiber spaces, which result in more contaminants being captured on the surface of the media. This can help keep restriction levels low as the filter loads with dirt and containments

If you look at the picture to the left, you can see the Nano-fiber web on top of our base media. That web, or SuperNano-Web as we like to call it, helps trap smaller particles and protect your engine.

To Clean your filter:

Carefully remove the filter from the housing. Once removed, wipe down the housing using a clean shop towel, being careful not to knock any dirt and/or debris in the air inlet. Your filters can be cleaned by carefully vacuuming the filter media from the dirty side, or by holding the filter with one hand and carefully blowing the filter media at a 45-degree angle from the clean side using low-pressure shop air (15-20 lbs. psi).

****IT IS IMPORTANT TO NOT USE ANY CLEANERS ON THE SUPERNANO-WEB MEDIA OR APPLY ANY OIL!!!***

NOTE: DISCONNECT BATTERY BEFORE INSTALLATION!!!


Instruction Manual P/N:SP1350




1. Stock intake system shown.



2. Loosen and remove the 2 strut braces on passenger and driver side.




7. Loosen the 3 bolts holding in the OEM air box for both sides using 10 mm socket with ratchet.



3. Loosen clamp on air box on both sides using 10mm socket or nut driver.



4. Carefully lift up and remove the air box on both sides.



5. On driver side only, Loosen clamp and pull back vacuum line from engine.



6. On driver side only, loosen clamp and pull back the crank case line from engine.



7. Loosen the clamp on the turbo using 10mm socket or nut driver on both sides.



8. On both sides, loosen clamp and pull back the diverter valve.



9. Remove the intake tube from both sides.



10. Loosen the 2 bolts holding in the plastic air box inlet using 10mm socket or wrench and remove on both sides.



11. Both stock intakes removed from vehicles.

Instruction Manual P/N:SP1350




12. Install the provided vibramount to the original air box mounting insert on passenger side. Secure and tighten.




13. Install the provided vibramount to the original air box mounting insert on driver side. Secure and tighten.



14. Install the provided 2-1/4" straight hose to the turbo on both sides with clamps. Tighten clamp on turbo only using 8mm nut driver.



15. Install the Driver side tube and position the bracket to the vibramount and turbo. Do not tighten.



16. Install the provided 12mm hose to the crank case fitting and 10mm hose to the vacuum fitting.




17. Attach the crank case and vacuum line to the intake tube. Attach the diverter line to the large fitting on intake tube.




18. Secure the bracket on driver side using provided fender washer and nut. Position intake for the best fit and tighten clamps using 8mm nut driver.



19. Install the passenger side tube and position the bracket to the vibramount and turbo. Attach the diverter line to the large fitting on intake tube. Do not tighten.




20. Secure the bracket on passenger side using provided fender washer and nut. Position intake for the best fit and tighten clamps using 8mm nut driver.




21. Install the air filter to the passenger side and tighten using 8mm nut driver. Re-adjust if necessary for best fit.



22. Install the air filter to the driver side and tighten using 8mm nut driver. Re-adjust if necessary for best fit.



23. RE-install the strut braces to the vehicle.



Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose. **Note: Check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.**

Test Drive:

1. With the transmission in neutral or park and the parking brake engaged, start the engine. Listen for air leaks or odd noises. If air leaks are detected, secure hoses and connections. For any odd noises, inspect entire system for cause and adjust intake as needed. The Injen intake will function identically to the factory system but will be louder and more powerful.
2. Perform a road test. Listen for odd noises or rattles and fix as necessary.
3. If there are no issues, continue to enjoy your added performance from the Injen performance Intake kit.
4. Injen Technology recommends you periodically check clearance and adjust if needed! Failure to check the alignment and adjust the intake can cause damage that will void the warranty. Injen Technology is not responsible for any damages caused by/from improper installation.

1. Upon completion of the installation, reconnect the negative battery terminal before you start the engine.
2. Align the entire intake system for the best possible fit. Once the intake has been properly fitted continue to tighten all nuts, bolts and clamps.
3. Periodically, recheck the alignment of the intake system and make sure there is proper clearance around and along the length of the intake. Failure to follow proper maintenance procedures may cause damage to the intake and will void the warranty.
4. Start the engine and listen carefully for any odd noises, rattles and/or air leaks prior to taking it for a test drive. If any problems arise go back and check the vacuum lines, hoses and clamps that maybe causing leaks or rattles and correct the problem.
5. Check the filter for excessive dirt build up. Clean or replace the filter with an original Injen filter (can be bought on-line at "injenonline.com"). Congratulations! You have just completed the installation of the best intake system sold on the market. Enjoy the added power and performance of your new intake system.