

Fitting Instructions #4351IS

SPF4351 – 10, 12, 15, 16, 17

Camber Pin Kit (Front)

- Before starting the job, wheel align the vehicle to determine the required amount of camber change;
- With the vehicle on jack stands/hoist, remove tyre and wheel assemblies;
- Remove the upper strut bolt.
- Line up small tab with cam on bolt. Install bolt with large tab out toward wheel for negative camber. Install SuperPro camber bolt into strut hole making sure the small tab on the washer is in the hole and the washer is flush on the strut. Install lock nut, but do not tighten at this stage. Loosen the lower bolt;
- Reinstall the wheels and adjust SuperPro camber bolt to achieve desired camber result (see figure below);
- When all settings are defined, torque all bolts to manufacturer's specifications and carry out wheel alignment;



More negative camber



More positive camber