



# QL-K1016

**Chevy Trailblazer 2002 - up**

**GMC Envoy 2002 - up**

**Oldsmobile Bravada 2002 - 04**

**Buick Rainier 2004 - up**

## FACTORY KICKPANEL REMOVAL:

Drivers Side:

Remove the tree lock at the top of the factory threshold panel. Gently pry up on the lower portion of the panel, releasing it from the front 2 clips. Pull back the carpet, exposing the foam dead pedal block. Remove the block and replace the carpet.

Passenger side:

Remove two(2) 7mm screws securing the under dash cover. Pull the cover down and remove the two(2) tree lock tabs. Remove the cover from the vehicle. Remove the tree lock at the top of the factory threshold panel. Gently pry up on the lower portion of the panel, releasing it from the front 2 clips.



***Note: Always check the fit of the Q-Forms panel in the vehicle BEFORE any cutting or modifications are done!***

## SPEAKER INSTALLATION:

Cut the speaker holes in the Q-Forms before installing the panels in the vehicle. Using a hole saw of the correct size, position the pilot drill on the dimple at the center of the speaker mounting surface. Be careful as the hole saw exits the rear of the panel. Install speaker wiring and crossover network as per manufacture's instructions. Install tweeters as per manufacture's instructions. Install midrange drivers after Q-Forms panels have been installed in the vehicle.

### Supplied Hardware:

2 - Color matched Grills  
6 - #8 x 1/2" Sheet Metal Screws  
2 - Polyfill Sheets  
1 - Foam Tape Roll  
40" - "U"-channel

## Q-FORMS KICKPANEL INSTALLATION:

Driver side installation:

Push down the carpet in the dead pedal area. Place the Q-Form kickpanel against the sidewall and locate the upper tab into the factory cutout in the sheet metal. Push the panel down while rotating towards the firewall. Hold the panel in place with one hand and check the fit by replacing the threshold panel and tree lock. The threshold panel should rest in the recess of the Q-Forms kickpanel. Remove the tree lock and threshold panel. Check the area behind the mounting tabs for any wiring harnesses, then secure the panel using three(3) of the supplied #8 x 1/2" sheet metal screws through the pre-drilled hole in each tab and into the sheet metal. Replacing the threshold panel and tree lock. Lay the supplied polyfill in and around the opening for the midrange driver, and install the midrange driver as per manufacturer's instructions. Be sure to center driver in opening to allow clearance for the speaker grill. Cut the supplied "U" channel into two equal pieces. Install the rubber "U" channel over and around the edge of the supplied grill. Press the grill into the grill opening.

Continued on other side:

**Continued from other side:**

## **Q-FORMS KICKPANEL INSTALLATION:**

### **Passenger side installation:**

Place the Q-Form kickpanel against the sidewall and locate the upper tab into the factory cutout in the sheet metal. Push the panel down while rotating towards the firewall. Hold the panel in place with one hand and check the fit by replacing the threshold panel and tree lock. The threshold panel should rest in the recess of the Q-Forms kickpanel. Remove the tree lock and threshold panel. Check the area behind the mounting tabs for any wiring harnesses, then secure the panel using three(3) of the supplied #8 x 1/2" sheet metal screws through the pre-drilled hole in each tab and into the sheet metal. Replacing the threshold panel and tree lock. Lay the supplied polyfill in and around the opening for the midrange driver, and install the midrange driver as per manufacturer's instructions. Be sure to center driver in opening to allow clearance for the speaker grill. Cut the supplied "U" channel into two equal pieces. Install the rubber "U" channel over and around the edge of the supplied grill. Press the grill into the grill opening. Reinstall the under dash cover removed previously. Secure using the tree lock tabs and 7mm screws.



***Installation of your new Q-Forms kick panels is complete.***

***Start enjoying your front row - center stage seats!***



### **ONE YEAR LIMITED WARRANTY**

*Q-Logic warrants to the original retail purchaser, this product to be free from defective workmanship and material when used under normal conditions in accordance with the product's printed instructions for a period of one (1) year from date of purchase. Q-Logic agrees to remedy any such defect or to furnish a new part in exchange for the defective one at no charge for parts or labor. This warranty is limited to Q-Logic products and specifically excludes consequential damage to other associated equipment which may result for any reason from use with this product. In no event shall Q-Logic be liable for incidental or consequential damages or have any liability with respect to defects other than the obligations set forth above. Some states do not allow limitations on how long an implied warranty lasts, and/or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific rights and you may also have other rights which vary from state to state.*

*This warranty does not cover the following:*

- Damages caused by water, neglect, abuse, misuse.
- Improper installation or operation.
- Damages caused by acts of God or nature.
- Damages occurring during shipment of the product to Q-Logic for repairs.
- Any product which is modified without consent of Q-Logic.

*If you need warranty service, take the following steps:*

- 1. Save your sales receipt for warranty registration and service.*
- 2. Contact the dealer from whom you bought Q-Logic. They will give you instructions for warranty service.*
- 3. If no dealer is available, call Q-logic for further Instructions: (866) 680 - 2375.*

**You must receive an RA# before returning any defective parts.**

***For other cool Q-Logic products,  
visit our website!***

***<http://qlogic.ws>***

