

KABO KI STRENGTH

Kadillac Bar Sleeve Assembly Instructions

Hardware included is bolts (8), washers (8), and nuts (8). Begin by lining up the 4 bolt holes in the sleeve with the 4 bolt holes on the center of the bar.



Insert the sleeve into the hole in the bar center bracket. This is designed to have a snug fit and rotating the sleeve can help to work it into the slot. If necessary, tap in the sleeve with a rubber mallet or dead-blow hammer.



Continued on back...

Using all the included bolts, place a washer on them and then insert them through all four holes on both sides with the threads oriented toward the middle of the bar. From there, add a washer to the other side and secure with a nut. Do not tighten beyond 23 lb-ft of torque.

