



D-CAP

ASSEMBLY INSTRUCTIONS

- 1.** Remove the ferrules with pre-installed screws from the inner tray packaging and unscrew all screws from the ferrule using a 1/16" allen key.
- 2.** Take a blade from the packaging and rotate it into a flat face on the ferrule head so that the holes on the blade and ferrule align. Rotating the blade into position is critical as there is an undercut on the ferrule that will lock the blade into position once it is secured in place by the screw.
- 3.** Insert the screw through the hole in the blade and securely thread into the ferrule.
- 4.** Repeat steps 2-3 for remaining blades.

