



### HOW TO APPLY | *For All Generations*

1. Prepare your case and clean with Isopropyl wipe
2. Carefully peel off 3M industrial adhesive
3. Align indents and press firmly to adhere