## OF THE SUN OAK KITE'S TURTLE KITE

1. Lay kite face down

2. Bend and insert short white spar into head with ends in tabs A and B

3. Insert long white spars into bias tape on front flippers and ends into tabs C and D

- 4. Insert ends of yellow spar into bias tape on rear flippers
- 5. Secure velcro over spars
- 6. Attach line to bridle on front of kite and fly. In gusty winds, use a tail or drogue.

SUN OAK KITES, P.O.B. 232, ENGLISH, IN 47118 sunoakkites.com