

Make: Subaru

Model: 2015-2021 WRX STI

Application: Rocker Panel Guards


PACKAGE CONTENTS				TOOLS	
QTY		QTY			
2	Rocker Panel Guards - (Left & Right Sides)	4	1/4"-20 x 1" Socket Buttonhead Bolt	7/16" Socket/Wrench 5/32" Hex Key 1/4" Drill Bit 1/8"-3/8" Unibit/Drill Bit Set	
		4	3/8" Spacer		
8	1/4"-20 x 3/4" Socket Buttonhead Bolt				
24	1/4" Flat Washer				
12	1/4" Split Lock Washer				
12	1/4"-20 Nut				

INSTALLATION INSTRUCTIONS



Remove the factory rocker panels. Note: There are (5) large fasteners, (1) Screw, and the front mudflaps that need to be removed. Be careful when prying the panel off the car to preserve the factory clips.

1



Large fastener locations.

2



Rear screw location

3



Center the factory rocker panel on the guard as much as possible. Our test vehicle measured roughly 2 - 1/8" away from the front edge.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Helpful tip: Use a clamp to hold the two pieces in place while you drill the holes for mounting.

5



You can start installing the hardware as you move along drilling the mounting holes. Only (6) holes, spread out, across the entire rocker panel are needed. The orientation of the hardware is as follows: 1/4"-20 x3/4" bolt, 1/4" Washer, rocker panel guard, factory rocker panel, 1/4" Washer, 1/4" Lock Washer, and Nut.

6



Install the longer 1/4"-20 x1" bolts into the front and rear-most holes in the orientation as follows: 1/4-20" Bolt, 1/4" Washer, rocker panel guard, 3/8" spacer, factory rocker panel, 1/4" Washer, 1/4" Lock Washer, and Nut.

7



All the hardware installed and tightened down.

8



Reattach the rocker panels back to the vehicle.

Completed assembly shown.

9

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.