



Make: Ford

Model: 2013-2016 Fusion

Applications: 3-Piece Front Splitter

PACKAGE CONTENTS				TOOLS
QTY		QTY		7mm Socket 6mm Socket Wrench
1	Front Splitter Set	4	1/4 Split Lock Washer	
2	3/4" x 3/8" Nylon Spacer	4	1/4-20 Nut	
2	#8 x 2" Screw			
2	1/4" Washer USS			
4	1/4-20 x 3/4" Button Head Bolt			
4	1/4 SAE Washer			

## INSTALLATION INSTRUCTIONS



Remove (9) #8 screws from the front of the bumper. They are circled in white, respectively.

1



Attach the middle splitter to the car. Use the factory hardware for 3 middle holes as circled. **Note:** Do not screw in the holes on the side.

2



Install the side pieces using the 1/4" hardware. Only attach the hardware circled in white.

3



Slide the nylon spacer between the center and side pieces of the splitter. Attach the supplied #8 screw with the 1/4" washer.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.