



Make: FORD

Model: 2013-2014 Focus ST

Application: 3-Piece Aluminum Front Splitter

PACKAGE CONTENTS				TOOLS	
QTY		QTY			
1	Front Splitter - Center Piece			1/2" Socket or Wrench 3/16" Hex Key 3/8" Drill Bit	
2	Front Splitter - Side Piece				
8	5/16" - 18 x 1" Socket Buttonhead				
8	5/16" - 18 Hex Nut				
8	5/16" Lock Washer				
8	5/16" Flat Washer				

INSTALLATION INSTRUCTIONS



Remove indicated OEM splash guard screws as well as the ones at the rear of the splash guard.

1



Loosely fasten center piece with 5/16" Buttonhead Screw, Washer, Lock Washer, and Nut.

Note:

You may need to drill the holes out to 3/8" and pull down the splash guard for access.

2



Loosely fasten side pieces with 5/16" hardware.

3



Check fitment and tighten hardware.

NOTE: Center piece rests on TOP of side pieces.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Drill outermost holes on the center piece with a 3/8" drill bit.

5



Fasten with 5/16" Buttonhead Screw, Flat Washer, Lock Washer, and Hex Nut.

6



7