




Make: Ford

Model: 2017+ Focus RS

Application: 3-Piece Front Splitter


PACKAGE CONTENTS				TOOLS	
QTY		QTY			
1	Front Splitter - Center Piece			T27 Torx Driver	
2	Front Splitter - Side Piece			Philips Screwdriver	
13	1/4"-20 x .75" Buttonhead Screw			Flathead Screwdriver	
13	1/4"-20 Hex Nut			7/16" Wrench and Socket	
13	1/4" Lock Washer			6" Extension	
26	1/4" Flat Washer			5/32" Hex Key	
				5/16" Drill Bit	

INSTALLATION INSTRUCTIONS




Remove the felt splash guard.

1




Remove the plastic splash guard. Take note of the overlaps at the wheel well. Ignore the plastic clips indicated with an "X" above.

2



Attach the Center Piece with (5) 1/4" Buttonhead Screws, (10) Flat Washers, (5) Lock Washers, and (5) Hex Nuts.

3



Attach Side Pieces with (3) 1/4" Buttonhead Screws, (6) Flat Washers, (3) Lock Washers, and (3) Hex Nuts on each piece.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Insert plastic splash guard above the Splitter hardware.

5



Drill the (2) remaining holes in the Front Splitter through the plastic splash guard with a 5/16" Drill Bit.

6



Reach above the splash guard and insert (1) 1/4" Buttonhead Screw, (2) Flat Washers, (1) Lock Washer, and (1) Hex Nut through the last holes.

7



Reattach felt splash guard.

8