



Make: FORD

Model: 2014-2016 Fiesta ST

Application: Light Conversion

PACKAGE CONTENTS				TOOLS	
QTY		QTY			
2	Baja Designs Squadron Pro/Sport			7/16" Socket 7/16" Wrench T25 Torx Driver 5/32" Hex Key	
2	Mounting Bracket				
4	1/4" - 20 x 3/4" Hex Bolt				
4	1/4" - 20 Hex Nut				
8	1/4" Flat Washer				
4	1/4" Lock Washer				

## INSTALLATION INSTRUCTIONS



Gain access to the fog lights from behind the bumper. You may pull back the fender liner or remove the bumper entirely.

1



Remove the (2) T25 Torx Screws circled.

2



Replace Baja Designs Squadron Brackets with supplied Mounting Brackets. Tighten so that the brackets are parallel to the face of the fog light.

3



Install the assembly onto the bumper with the OEM screws.  
Optional: Replace plastic clips with supplied 1/4" hardware.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Adjust the assembly if necessary and tighten hardware.  
Do NOT overtighten as it may damage the plastic.

5



Note: It is normal for a small gap to be present between the lights and bezel.

6

Install wiring prior to re-installing the bumper cover.

**Optional:**

Splice the wires from the OEM fog harness so it can switch on independently like the OEM fog light.

**For optional pigtail adapter:**

Assemble the Baja Designs connectors onto the free ends of the pigtails. Check polarity prior to final assembly. Done correctly, the Squadrons will turn on with the OEM fog switch.

7