

Make:

Model:

2010-2014 Mustang

Ford

Application:

Rear Splitter

PACKAGE CONTENTS				TOOLS
QTY		QTY		5/16", 1/8" Drill Bit
2	Rear Splitter			4mm Hex Key
4	5/16"-18 x 1.00" Buttonhead Bolt	2	1/4"-20 x 1.00" Buttonhead Bolt	3/16" Hex Key
4	5/16"-18 Hex Nut	2	1/4"-20 Hex Nut	Flat Head Screwdriver
4	5/16" Lock Washer	2	1/4" Lock Washer	Philips Offset Screwdriver
4	5/16" Flat Washer	2	1/4" Flat Washer	7/16", 1/2" Socket/Wrench

INSTALLATION INSTRUCTIONS

1



Remove the (2) plastic rivets that hold the bumper to a plastic structure on both sides of the vehicle.



Remove (2) screws behind the rear tire, on both sides of the vehicle.



Hold the splitter up to the bumper and ensure the front of the splitter seats flush with the arc of the wheel well.

(Image above for reference only; vehicle may differ)



After aligning the splitter, use the (3) splitter holes to mark the centerline holes for drilling. The rear-most hole may already exist in the bumper and does not require any drilling.

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.

3

4

2



Drill 5/16" size holes where you marked your centermarks (use a 1/8" bit first to create a pilot hole).



Completed assembly.



Install rear splitter using (1) 1/4" Buttonhead bolt, Washer, Lock Washer, and Hex Nut on the rear most mounting hole. Install (2) 5/16" Buttonhead bolts, Washers, Lock Washers, and Hex Nuts on the remaining mounting holes. Reinstall plastic rivets and screws removed in steps 1-2.

5

7

6