



Make: Ford

Model: 2018 Mustang

Application: Rear Splitter

PACKAGE CONTENTS				TOOLS	
QTY		QTY			
2	Rear Splitter			3/8" Drill Bit	
6	5/16"-18 x 1.00" Buttonhead Bolt			1/2" Socket and Wrench	
6	5/16"-18 Hex Nut			3/16" Hex Key	
6	5/16" Lock Washer			Flat Head Screwdriver	
6	5/16" Flat Washer			2x Holding Clips (ex. binder clips)	

INSTALLATION INSTRUCTIONS




Remove (2) large plastic rivets that hold the bumper to a plastic structure to allow easier access for installation.

1



Align the front edge of the splitter to the wheel arc. Use holding clips to help keep the splitter in place temporarily.

2



Confirm that both left and right splitter are consistent in alignment (fin, bumper outline, and exhaust clearance).

3



After aligning the splitter, use the (3) splitter holes to mark the centerline holes for drilling.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



After confirming alignment of the rear splitter and marking the holes, drill the (3) holes with a 3/8" drill bit.

5



Fasten the 3 holes with (1) 5/16" -18x1.00" Buttonhead Bolt, (1) Flat Washer, (1) Lock Washer, and (1) Hex Nut on each hole.

Reattach the OEM plastic rivets.

6



Repeat process for other side.

7

