



Make: Ford

Model: 2021+ Bronco Sport (1.5L Models)

Application: Skid Plate

PACKAGE CONTENTS				TOOLS	
QTY		QTY		QTY	
1	Skid Plate	2	M10 Flat Washer		12mm Wrench/Socket
2	M10 x 90mm Hex Head Bolt	2	M8 Flat Washer		13mm Wrench/Socket
2	5/8" Long Round Spacer (Wider)				14mm Wrench/Socket
2	M8 x 50mm Hex Head Bolt				17mm Wrench/Socket
2	1.25" Long Round Spacer				

## INSTALLATION INSTRUCTIONS

Locate and remove the (1) M8 Hex Head bolt & (1) M10 Hex Head bolt (rear) underneath the front of the vehicle. Passenger side shown.

1

Remove the same bolts on the driver side.

2

Carefully raise the plate against the vehicle, aligning the holes with the holes on the vehicle.

3

Place the 5/8" spacers between the rear-most holes on the skid plate and the chassis. Insert the new M10 Bolts into the holes and thread them into the chassis. Orientation: (1) M10 Bolt, (1) M10 Washer, skid plate, short spacer.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Place the 1.25" round spacers between the front holes on the skid plate and the chassis. Insert the new M8 Bolts into the front holes and thread them into the chassis. Orientation: (1) M8 Bolt, (1) M8 Washer, skid plate, long spacer.

5



Tighten all bolts.

Completed assembly shown.

6