



Make: Saab

Model: 2005-2006 9-2X

Application: Rally Light Bar

PACKAGE CONTENTS				TOOLS	
QTY		QTY		QTY	
1	Rally Light Bar	4	3/8"-16 Hex Nut		9/16" Socket/Wrench 7/16" Socket/Wrench Panel Removal Tool
1	Lower Brace	6	3/8" Split Lock Washer		
1	License Plate Bracket	10	3/8" Flat Washer		
2	3/8" Bolt Plate	2	1/4" Flat Washer		
4	3/8"-16x 1" Hex Bolt	2	1/4" Lag Screw		
2	3/8"-16x 1.75" Hex Bolt				

## INSTALLATION INSTRUCTIONS



Remove the factory splash guard. Locate holes (shown above) on lower bumper beam. There is one on each side (L+R) of the car.

1



Insert the bolt plate through the larger hole and have the threads come out of the smaller hole like shown above.

2



Attach the mounting brace to the lower bumper beam by using (1) 3/8" Flat Washer, (1) 3/8" Lock Washer, (1) 3/8"-16 Hex Nut. Repeat on the opposite side.

3



Attach the License Plate Bracket to the bumper using (1) 1/4" Lag Screw and (1) 1/4" Flat Washer in each mounting hole to the factory location.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Attach the light bar to License Plate Bracket using (1) 3/8"-16x 1" Hex Bolt, (2) Flat Washer, (1) Lock Washer, and (1) 3/8" Hex Nut for each side.

5



Attach the light bar to the lower brace using (1) 3/8"-16x 1", (1) 3/8" Lock Washer, and (1) 3/8" Flat Washer on each side. Tighten all 3/8" hardware to 33 ft-lbs. Trim bumper as needed to clear the light bar mounting to the brace (shown with arrows).

6



Completed assembly shown.

7