



Make: Subaru

Model: 1995-1999 Outback

Application: Rally Light Bar

PACKAGE CONTENTS				TOOLS
QTY		QTY		
1	Rally Light Bar	6	3/8" -16 Nut	Flathead Screwdriver 9/16" Socket or Wrench 1/2" Socket or Wrench
1	Mounting Bracket	2	3/8" -16 x 1.75" Hex Bolt	
2	L-Bracket	2	5/16" -18 x 1.5" Hex Bolt	
2	M8 x 25mm Hex Flanged Bolt	6	5/16" SAE Flat Washer	
4	3/8" - 16 x 2" Hex Bolt	4	5/16" Split Lock Washer	
12	3/8" SAE Flat Washer	2	5/16" -18 Nut	
6	3/8" Lock Washer	4	3/4" Long Plastic Spacer	

INSTALLATION INSTRUCTIONS

Locate threaded mounting holes in the lower radiator support.

1

Attach Mounting Brace to the lower radiator support using (1) M8 Bolt, (1) Lock Washer, and (1) Flat Washer per side. Note the orientation of the Mounting Bracket with the light bar mounting ends pointing forward. Tighten and torque to 18 ft. lbs.

2

Install (1) 5/16" Flat Washer through rectangular opening on the lower grille opening of the bumper cover. Press Washer firmly against the backside of the license plate hole.

3

Assemble (1) 5/16" Bolt, (1) Flat Washer, (1) L-bracket and (1) plastic spacer as shown, with the slotted side up, facing forward. Pass the Bolt through the bumper cover with the previously installed Flat Washer on the back side and complete assembly using (1) 5/16" Split Lock Washer and (1) 5/16" Nut. Tighten to 15 ft. lbs. Repeat for other side.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Position plastic spacers on top of "L" Brackets as shown.

5



Place Light Bar on top of plastic spacers. Use (1) 3/8"-16x1 Hex Bolt, (2) 3/8" Washers, (1) 3/8" Split Lock Washer, and (1) 3/8"-16 Hex Nut. Assemble loosely.

6



Attach the Light Bar to the Mounting Bracket using (2) 3/8" x 2" Hex Bolt, (4) Flat Washers, (2) Split Lock Washers, and (2) Hex Nuts per side.

7



Additional view from Step 7. Note there are also Flat Washers on the other side of the mounting brace. Once Light Bar is in place, tighten and torque 3/8" hardware to 30 ft lbs.

8



Finished install of the light bar. Baja Designs XL-R lights are shown.

9