


Make: Subaru

Model: 2000-2004 Outback  
2002-2006 Baja

Application: Rally Light Bar


PACKAGE CONTENTS				TOOLS	
QTY		QTY			
1	Rally Light Bar	6	3/8"-16 Nut	Flathead Screwdriver 9/16" Socket or Wrench 7/16" Socket or Wrench Sharp Cutting Tool	
2	Mounting Bracket	2	3/8"-16 x 1" Hex Bolt		
2	L-Bracket	2	1/4" x 1" Lag Screw		
2	5/16" Bolt Plate	2	1/4" USS Washer		
4	3/8" - 16 x 2" Hex Bolt	2	5/16"-18 Nut		
12	3/8" SAE Flat Washer	2	5/16" Washer		
6	3/8" Lock Washer	2	5/16" Lock Washer		

## INSTALLATION INSTRUCTIONS




Remove the plastic splash guard.  
Insert (2) 5/16" Bolt Plates into the holes shown above.

1




Attach a Mounting Bracket to the Bolt Plates, for each side. Fasten with (1) 5/16" Flat Washer, (1) 5/16" Lock Washer, and (1) 5/16"-18 Hex Nut per side. Note the orientation of the Mounting Bracket with the shorter end pointing forward.

2



Attach the Light Bar to the Mounting Bracket using (2) 3/8" x 2" Hex Bolt, (4) Flat Washers, (2) Lock Washer, and (2) Hex Nut per side.

3



Additional view from Step 3. Note there are also washers on the other side of the bracket.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Install L-bracket as shown, with the slotted side mounted on the bumper. Slotted hole - Use 1/4" x 1" Lag Screw and 1/4" USS Washer to mount into the bumper.

5



L-bracket installation (continued): Light bar mounting tab will line up over the L-bracket as shown. Fasten using (1) 3/8"-16x1 Hex Bolt, (2) 3/8" Washers, (1) 3/8" Lock Washer, and (1) 3/8"-16 Hex Nut on each side.

6



Finished install of the light bar.

7