

Make: Subaru

Model: 2000-2001 Impreza RS

Application: Fog Light Conversion

PACKAGE CONTENTS			TOOLS
QTY		QTY	7/16" Socket/Wrench
2	Fog Light Mounting Brackets		10mm Socket/Wrench
2	#10 x 1/2" Philips Screws		Philips Screwdriver
6	M6 - 1.0 x 16mm Hex Head Bolts		9/64" Drill Bit

INSTALLATION INSTRUCTIONS

1



Remove factory fog light and fog light splash guard to gain access to fog light area behind front bumper.



Mount the fog light bracket to the bumper temporarily (using M6 hex head bolts) to mark the additional mounting hole for drilling (use 9/64" drill bit).

2



Remove fog light mounting bracket from the vehicle and fasten the new fog light onto it. Install the new fog light assembly onto the vehicle using (1) #10 screw and (3) M6 hex head bolts. Repeat steps on the other side.



Complete assembly shown.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.

3