




Make: Subaru

Model: 1993-2001 Impreza

Application: Ultimate Light Bar


PACKAGE CONTENTS				TOOLS	
QTY		QTY			
1	Ultimate Light Bar	1	Rally Skid Guard	Flathead Screwdriver Cutting Tool 10mm Wrench and Socket 1/2" Wrench and Socket 9/16" Wrench and Socket	
2	Lower Mounting Bracket	10	3/8" Flat Washer		
2	Upper Mounting Brackets	6	3/8" Lock Washer		
2	5/16" Bolt Plate	2	5/16" Flat Washer		
2	3/8" -16 x 3/4" Hex Bolt	2	5/16" Lock Washer		
2	3/8" -16 x 1" Hex Bolt	4	3/8" -16 Nut		
2	3/8" -16 x 2" Hex Bolt	2	5/16" Nut		
2	M8 X 1.25 X 25mm Bolt				

INSTALLATION INSTRUCTIONS




Remove the front grill by pushing down on the release tabs with a flat head screw driver.

1



Undo the bolts in between the headlight mounting bolts remove them along with the spacers.

2



Slide the passenger side upper mounting bracket behind the front of the car as pictured above & reinstall the factory bolts & spacers.

3



Install the The driver side upper mount bracket using the factory bolt and spacer as pictured above.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Locate the two holes in the lower radiator support, and place the 5/16" bolt plate into the non-threaded hole [Passenger side shown]

5



Attach the mounting bracket to the car using the M8-1.25 x25mm bolt, and (1) 5/16 flat washer, (1) 5/16 lock washer, and (1) 5/16 nut fastened on the bolt plate.

6



Trim the OEM grill as shown to fit over the Ultimate Light Bar. After the grill has been trimmed, slide it onto the ULB.

7



Align the upper mounting brackets with the holes in the the upper tubes & fasten using a (1) 3/8"-16 x 2" Bolt, (2) 3/8" Flat Washers, (1) 3/8" Lock Washer, & 3/8" Nut per side.

8



Attach the Rally Skid Guard to the lower mounting brackets using (1) 3/8"-16 x 1" Bolt, (2) 3/8" Washers, (1) 3/8" Flat Washer, & (1) 3/8" Nut on each side, but do not tighten.

9



Fasten the front of the Rally Skid Guard to the light bar using (1) 3/8"-16 x 3/4", (1) 3/8" Flat Washer, & (1) 3/8" Lock Washer per side . Tighten all hardware and reattach the front grill.

10

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.