



MAKE: SUBARU
 MODEL: 2002 – 2003 Impreza WRX/RS
 PART: Rally Skid Guard

PACKAGE CONTENTS				TOOLS
QTY		QTY		
1	Rally Skid Guard	2	½" ID, ¾" Tall Nylon Spacer	Ratchet
2	Mounting Brace	2	3/8"-16 x 1 ¼" Hex Bolt	9/16" Wrench
2	L-bracket	2	3/8"-16 x 1" Hex Bolt	9/16" Socket
1	Z-bracket	6	3/8"-16 Nut	1/2" Wrench
1	Upper Bar	4	3/8"-16 x ¾" Hex Bolt	1/2" Socket
3	5/16" Flat Washer	12	3/8" Flat Washer	15mm Socket
3	5/16" Lock Washer	8	3/8" Lock Washer	
3	5/16"-18 x 1" Hex Bolt			
1	1/4"-20 Nyloc Nut			
1	1/4"-20 x 3/4" Hex Bolt			

INSTALLATION INSTRUCTIONS

Driver side shown

Locate the two holes in the lower radiator support, and remove the 15mm bolt in the forward hole. Save this bolt for future use.

1

Note: Factory splash guards may need to be partially removed to gain access to the mounting point on the lower sub-frame.

2

Passenger side shown

Attach the mounting bracket to the car using the factory bolt, and (1) 3/8" flat washer in the forward location. Attach the rear tab using (1) 3/8"-16x1 ¼" hex bolt, (2) 3/8 flat washer, (1) nylon spacer, (1) 3/8 lock washer, and (1) 3/8 nut.

3

Mount the the Z-bracket to the lower radiator support using (1) 1/4"-20 x 3/4" hex bolt, and (1) 1/4"-20 nyloc jam nut.

4



Attach the upper bar of the Skid Guard to the Z-bracket using (1) 5/16"-18x1" hex bolt, (1) 5/16" flat washer, and (1) 5/16" lock washer.

5



Mount the Skid Guard to the lower brackets using (1) 3/8"-16x1" hex bolt, (2) 3/8" flat washer, (1) 3/8" lock washer, and (1) 3/8"-16 nut.

6



Mount the Skid Guard to the upper bar using (1) 3/8"-16x 3/4" hex bolt, (1) 3/8 flat washer, and (1) 3/8" lock washer.

7



Attach the L-bracket to the upper bar using (1) 5/16"-18 x 1" hex bolt, (1) 5/16" flat washer, and (1) 5/16" lock washer. Insert (1) 3/8"-16 x 3/4" hex bolt, (1) 3/8" lock washer, and (1) 3/8"-16 nut into the hole of the L-bracket.

8