



MAKE: SUBARU
 MODEL: 2002 – 2003 Impreza RS/WRX
 PART: Ultimate Light Bar


PACKAGE CONTENTS				TOOLS
QTY		QTY		
1	Ultimate Light Bar	18	3/8" Flat Washer	Ratchet
2	Mounting Bracket	8	3/8" Lock Washer	9/16" Wrench
2	Nylon Spacer	6	3/8" Nut	9/16" Socket
2	3/8"-16 x 0.75" Hex Bolt			1/2" Wrench
2	3/8"- 16 x 1" Hex Bolt			1/2" Socket
2	3/8"- 16 x 1 3/4" Hex Bolt	2	M8 Bolt	5/8" Socket
2	3/8"- 16 x 2" Hex Bolt			

INSTALLATION INSTRUCTIONS



Remove the factory splash guard.

1




Locate the two holes in the lower radiator support, and remove the bolt in the forward hole. Save this bolt for future use. [Passenger side shown]

2



Note: Factory splash guards may need to be partially removed to gain access to the mounting point on the lower sub-frame.

3



Passenger side shown

Attach the mounting bracket to the car using the factory bolt, and (1) 3/8" flat washer in the forward location. Attach the rear tab using (1) 3/8"-16x1 3/4" hex bolt, (2) 3/8 flat washer, (1) nylon spacer, (1) 3/8 lock washer, and (1) 3/8 nut.

4



Attach the upper brackets by removing the radiator support screw.

Note: It is easier to install by removing the grille (release 4 tabs to loosen grille)

5



Attach the grille back on and insure all the clips are fastened.

6



Attach the ultimate light bar by using (1) 3/8"-16 x 2" hex bolt, (2) 3/8 washer, (1) 3/8 lock washer, and (1) 3/8 nut.

7



With the ultimate light bar hanging, attach the bottom of the aluminum skid guard to the lower brackets using (1) 3/8"-16 x 1" hex bolt, (2) 3/8 washer, (1) 3/8 lock washer, (1) 3/8 nut. Tighten all 3/8 hex bolt to 32 ft-lb. Tighten all M8 Bolt to 25 N-m (19 ft-lb).

8