



Make: Subaru

Model: 2008-2010 Impreza WRX

Application: Fog Light Conversion

PACKAGE CONTENTS				TOOLS	
QTY		QTY		QTY	
2	Fog Light Mounting Bracket	4	1/4" Flat Washer		10mm Socket/Wrench
2	3/8"-16 x 1" Hex Bolt	2	1/4" Split Lock Washer		7/16" Socket/Wrench
4	3/8" Flat Washer	2	1/4"-20 Hex Nut		9/16" Socket/Wrench
2	3/8" Split Lock Washer				3/8" Drill Bit
2	3/8"-16 Hex Nut				Panel Removal Tool
2	1/4"-20 x 3/4" Hex Bolt				

INSTALLATION INSTRUCTIONS



Remove fog light splash guard by unfastening the plastic clip and 10mm head screw securing it and pulling it downward.

1



Remove the factory fog light by unfastening the factory hardware. There are (3) fasteners that need to be removed to free the fog light. Note: Aftermarket Fog Light shown, factory fog light will look different but attaches to the same mounting points.

2



Enlarge the hole on the plastic bumper mounting tab with a 3/8" drill bit to accommodate the new 3/8" mounting hardware.

3



Take the new mounting brackets and assemble the fog lights in them (as shown above) with the included fog light hardware.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



The driver side assembly mounts as shown. Insert (1) 3/8"-16 x 1" Hex Bolt and (1) 3/8" Flat Washer through the fog light bracket and bumper mounting tab. Then fasten with 3/8" Flat Washer, Split Lock Washer and Hex Nut.

5



Insert (1) 1/4"-20 x 3/4" Hex Bolt through the top bumper mounting tab and fog light bracket. Fasten on the other end with (1) 1/4" Flat Washer, Split Lock Washer, and Hex Nut.

6



Confirm the position of the light in the bumper fog light hole is center and tighten all hardware. Repeat the process on the passenger side.

7



Completed assembly shown.

8