




Make: Subaru

Model: 2009-2013 Forester

Application: Rally Light Bar

PACKAGE CONTENTS				TOOLS	
QTY		QTY			
1	Rally Light Bar	6	3/8" - 16 Hex Nut	Flathead Screwdriver Cutting Tool Sander/Grinder 10mm Wrench and Socket 9/16" Wrench and Socket	
1	Lower Mounting Brace	10	3/8" Flat Washer		
1	Upper Mounting Brace	6	3/8" Lock Washer		
2	3/8" Bolt Plate				
2	3/8" - 16 x 2.5" Hex Bolt				
2	3/8" - 16 x 1" Hex Bolt				

INSTALLATION INSTRUCTIONS




Remove the lower splash guard and insert (2) Bolt Plates into the slots shown.

1




Attach the Lower Brace with (1) 3/8" Flat Washer, (1) Lock Washer, and (1) Hex Nut per side.

2



Partially remove the front bumper from the top and remove the (2) bolts on the bumper beam shown above.

3



Insert the Upper Brace behind the bumper cover. Slide the tabs through the openings under the grill.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.



Attach the Upper Brace to the bumper beam with the factory bolts from Step 3.

5



Attach the Light Bar to the Upper Brace with (1) 3/8" x 1" Hex Bolt, (2) Flat Washers, (1) Lock Washer, and (1) Hex Nut per side.

6



Attach the Light Bar to the Lower Brace with (1) 3/8" x 2.5" Hex Bolt, (2) Flat Washers, (1) Lock Washer, and (1) Hex Nut per side.

7