

Make: Subaru

Model: 2013-2019 BRZ

Application: 3-PC Front Splitter

PACKAGE CONTENTS					TOOLS
QTY		QTY	QTY	<i>(</i>	1/2" Socket/Wrench
1	Front Splitter - Center Piece				3/16" Hex Key
2	Front Splitter - Side Piece				Panel Removal Tool
8	5/16"-18 x 1" Socket Buttonhead				10mm Socket/Wrench
8	5/16" Flat Washer				Drill
8	5/16" Split Lock Washer				5/16" Drill Bit/Step Bit
8	5/16"-18 Nut				

## **INSTALLATION INSTRUCTIONS**

1



Remove factory splash guard by unfastening factory clips holding it in place.



Locate and unfasten the factory clips on the fog light splash guards - this will aid in installation. Locate the farthest right hole (circled above) and fasten the corner of the driver-side splitter loosely to hold it in place. Repeat on the passenger side.

2



Next place the center splitter piece inbetween both ends and clamp/hold the splitter pieces in place as you mark the mounting holes for drilling. Note the center piece rests on top of both end pieces. Drill holes out to 5/16 inch.



Insert (1) 5/16"-18 x1" Socket Buttonhead, (1) 5/16" Washer, (1) 5/16" Lock Washer, and (1) 5/16"-18 Nut into each mounting hole. Loosely fasten hardware initially, until all bolts are in. Make sure the splitters are aligned and then tighten them down.

4

DISCLAIMER FOR RALLY INNOVATIONS PRODUCTS: Buyers assume all risk and liability whatsoever for the installation and the use of Rally Innovations products. Rally Innovations products are sold as decorative accessories and should not be relied upon as protection for the vehicle or occupants in the event of a collision or roll over. Vehicles equipped with a supplemental restraint system (air bag) deployed by impact should not be modified by any aftermarket Light Bar or Skid Guard without first consulting the vehicle manufacturer. Rally Innovations, a subsidiary of Pentech Automotive assumes no liability for injury, loss, incidental or consequential damages in the event of a collision or roll over.

3



Reinstall the splashguard and factory clips in their original places.



Completed assembly shown.

5

6