



## CHE PERFORMANCE PRODUCTS INSTALLATION INSTRUCTIONS

### PANHARD BAR BRACE PART # CHE6N

APPLICATIONS: Mustang: 2005-Current  
Body Style: All  
Engine: All

***WARNING!!: If you lack the necessary skill, tools, or equipment to safely complete this installation, have the component installed by a mechanic with the proper equipment and expertise.***

Thoroughly read and understand these installation instructions before beginning the installation. If there is any doubt regarding the procedure, please contact CHE Performance prior to attempting installation

#### Step 1. Raise the Vehicle

With the front wheels properly blocked; raise the rear end of the vehicle as high as safely possible. Place jack stands on a solid area under the vehicle.

#### Step 2. Remove Passenger Side Bolt

Remove the nut and flag-bolt retaining the factory brace to the passenger side of the vehicle. Save the nut and flag-bolt for re-use.

#### Step 3. Loosen Panhard Bar Bolt

In order to free the brace from the vehicle, loosen the chassis side panhard bar bolt. *Do not completely remove the panhard bar bolt.*

#### Step 4. Remove Driver's Side Bolts

Remove the 2 bolts retaining the factory brace to the Driver's Side frame rail of the vehicle, and remove the brace. Save the bolts for re-use later.

#### Step 5. Install Brace

Using the factory hardware, install the CHE Panhard bar brace in the vehicle following the reverse procedure of removal.

#### Step 6. Torque Hardware

Torque the panhard bar bolt to 125 lb-ft  
Torque the Passenger Side brace bolt to 98 lb-ft  
Torque the Driver's Side bolts to 46 lb-ft

#### Step 7. Lower vehicle

Lower the vehicle and perform a road test.

#### Questions, Comments, Suggestions?

If you have any questions, comments, or suggestions regarding these instructions or product, please do not hesitate to contact us immediately. Thank you, and enjoy your new CHE Performance Product.

#### Technical Support/Contact Information

e-mail: [support@cheperformance.com](mailto:support@cheperformance.com)

Website: [www.cheperformance.com](http://www.cheperformance.com)