



# CHE Performance Products Installation Instruction Supplement 2005-Current S/T 8.8 Axle Brace Axle Housing Drilling Template

Note: Only required for vehicles without factory housing tab holes

## Step 1: Locate Drilling Templates



Cut out the templates at the bottom of this page following the dashed lines.

Adhere the templates to the axle housing as shown in photo at left using tape or other suitable alternative.

## Step 2: Drill Housing Holes



Mark the center of the holes onto the axle housing using a center punch.

Drill pilot holes in the axle housing using a small diameter drill bit

Remove the templates and enlarge the pilot holes to 9/16". If a 9/16" drill bit is unavailable, a 1/2" hole will be sufficient but may require slight enlargement with a round file or other suitable tool for proper axle brace fitment.

