

Wall Mounted Desk

- 1 The desk will hook onto two screws in a wall via the keyhole slots in the back of the unit.
- 2 To affix, measure the distance from the top of the unit to the top of the slots to find the first screw position.
- 3 Drill the first mounting hole and put in a wall plug and screw. Do not screw all the way in; leave a small length projecting so that you can hang the desk on it.
- 4 Measure the distance between the keyhole slots on the unit and measure that same distance on the wall to find the 2nd screw position.
- 5 Mark the position of the 2nd screw, using a spirit level to get the holes in line. Fit the 2nd screw.
- 6 The desk should then fit onto the 2 screws. Adjust the projection of the screws so the desk fits snugly to the wall.




TIPS

If you are mounting onto a plasterboard wall, try to select at least one of the fixings to coincide with a timber upright.

The head of the screw must pass easily into the hole of the fixing but not through the slot. 4mm or 5mm diameter screws will normally be appropriate.

Take care when fitting the unit on to the screws as the wall may not be flat and you should not force the unit onto the screws.