

Floating Shelves

- 1 The shelves will hook onto two screws in a wall via the keyhole slots in the back of the unit.
- 2 To affix, measure the distance from the top of the unit to the top of the slots to find the first screw position.
- 3 Drill the first mounting hole and put in a wall plug and screw. Do not screw all the way in; leave a small length projecting so that you can hang the bedside on it.
- 4 Mark the position of the 2nd screw, using a spirit level to get the holes in line. Fit the 2nd screw.
- 5 Measure the distance between the keyhole slots on the unit and measure that same distance on the wall to find the 2nd screw position.
- 6 The shelves should then fit onto the 2 screws. Adjust the projection of the screws so the shelves fits snugly to the wall.



TIPS

If you are mounting onto a plasterboard wall, try to select at least one of the fixings to coincide with a timber upright. Make sure to use appropriate fittings for plasterboard (the ones supplied are universal and will not suffice for plasterboard)

Take care when fitting the unit on to the screws as the wall may not be flat and you should not force the unit onto the screws.