

## Hallway Tidy

- 1 Remove the drawer from the unit (there is a drawer stop at the top, twist it to allow the drawer to slide out);
- 2 Once you have decided where the unit will go on the wall, make a small pencil mark where the first keyhole fitting will go;
- 3 Drill the first hole in the wall and insert the plug, put the screw in place but with a small amount projecting for the keyhole slot to sit on;
- 4 Measure the distance between the centre of the keyhole slot and the drilled hole at the other end of the unit (behind the drawer);
- 5 Use this measurement to make a second mark on the wall where the second screw will go into the wall. Use a spirit level to ensure that the two marks are completely straight;
- 6 Drill the second hole in the wall and insert the plug;
- 7 Pick the unit up and hook the keyhole slot onto the first screw. Adjust the screw if necessary to ensure it fits tightly to the wall.
- 8 Hold the unit in place and screw the second screw through the back of the unit behind the drawer. You will probably need two people to do this bit!
- 9 Replace the drawer.



### TO ADD THE MIRROR

- 1 Install the bottom mirror first (the smaller one). Measure 155mm from the left hand edge of the drawer and mark this distance.
- 2 Carefully measure the height from the top of the mirror to the underside of the saw-tooth fitting on the mirror. Add 2mm.
- 3 Using the measurement from 2, and a spirit level, mark the position of the screw hole. Using a punch or the screw make a hole at that position to guide the drill, then make the hole for the appropriate fitting.
- 4 Drill for the appropriate fitting and hang the mirror
- 5 Fit the screw, leaving the head projecting enough to catch the fitting. You can adjust to make the mirror level by moving along the teeth of the fitting.
- 6 For the top mirror, measure the distance from the bottom of the mirror to the saw tooth fitting and add 2mm, make a mark (you may need to remove the top mirror and unit to accurately do this)
- 7 Using a spirit level, measure up from the screw position used for the bottom mirror to make sure they are in line. Make a mark with a screw to guide the drill.
- 8 Fit the screw and hang the mirror in the same way as the previous one.