

Oak Desk

- 1 The desk will hook onto two screws in a wall via the keyhole slots in the back of the unit.
- 2 To affix, measure the distance from the top of the unit to the top of the slots to find the first screw position.
- 3 Drill the first mounting hole and put in a wall plug and screw. Do not screw all the way in; leave a small length projecting so that you can hang the desk on it.
- 4 Measure the distance between the keyhole slots on the unit and measure that same distance on the wall to find the 2nd screw position.
- 5 Mark the position of the 2nd screw, using a spirit level to get the holes in line. Fit the 2nd screw.
- 6 The desk should then fit onto the 2 screws. Adjust the projection of the screws so the desk fits snugly to the wall.



If you are mounting onto a plasterboard wall, select at least one of the fixings to coincide with a timber upright.

Use appropriate plasterboard fittings, the ones supplied are not appropriate for plasterboard.

If you are putting very heavy items on the unit, or if you are concerned about your wall strength, use the two brackets provided to provide extra support under the desk.