

Tacoma Roof Rack Install Instructions

- **Contents:**
- 5 ribs
- 2 sides
- 2 color match panels
- **Front fairing**

Rear fairing

4 roof brackets

Hardware bag

- 1. Identify the 2 different ribs. There are 2 that are slightly shorter than the rest. They are marked with a small hole in between the nutserts on the ends.
- 2. Loosely attach the 3 ribs into the slotted holes in the sides. Make sure you sandwich the color match panel with the hardware.
- 3. Loosely attach the front and rear fairings The front fairing is attached with bolts and nutserts and the rear is attached with bolts and nylock nuts.

- 4. You will now need to remove the plastic trim in the rain gutter to access the factory nutserts in the roof. They are covered with a silver foil tape. With your finger identify the holes and trim the foil with a razor blade.
- 5. You will now need to weatherproof the holes BEFORE you put the metric hardware in. Take silicone and fill the hole and the small area around the hole and then place the black spacers over the hole. Now you can loosely attach the 4 brackets to the roof.
- 6. Place something on your roof to prevent any scratching i.e. a blanket so you can rest the partially assembled rack on your roof.
- 7. Take the two short ribs and the provided longer hardware and sandwich the sides, brackets and the ribs together. Once all hardware is loosely in place and the rack is in place, start tightening the brackets to the roof.
- 8. After roof brackets are tight then tighten all the button head hardware.
- 9. Cut the plastic trim to go back into the rain gutter on either sides of the brackets.
- 10. Affix Hooligan stickers for added crawling prowess and aerodynamic advantage.